

# Getting Started with the C-pen Reader for Exams and

## Textbooks:

### For use with Textbooks:

How to use:

1. Power on the Device. (Make sure the product is charged.) Press the On/Off button for three seconds to power on ReaderPen (boot sequence takes about 10 seconds).
2. Select LEFT or RIGHT HAND. Select whether to use the product with left or right hand. Enter Settings\Left/Right-Handed to select. Press OK to confirm and then Back to get back to Main menu and select function.
3. Select a FUNCTION to get started with.
  - a. FUNCTION – TEXT READER: Reads text out loud.
  - b. FUNCTION – DICTIONARY: Looks up words in dictionaries and shows definition.
  - c. FUNCTION – SAVE TO FILE: Scan and save text and excerpts from textbooks. Files can be retrieved and listened to at any time.
  - d. FUNCTION – RECORDER: Record voice memos.

More Information about the C-pen Reader can be found in these in-depth guides.

[Getting Started Guide](#)

[Interactive User Guide](#)

Video demonstration:

[First use reader pen tutorial](#)

## [Setting up the C-pen](#)

### **For use with Exams:**

EXAMLOCK: By enabling Exam Lock, all functions but Text Reader are disabled. Useful if the ReaderPen shall be used in tests where access to stored content (text files or voice memos) or dictionaries are not allowed.

How to use:

1. Go to SETTINGS and select EXAM LOCK,
2. To lock the device, select LOCK,
3. Upon activation a PIN code is entered. Chose a PIN code of your liking and one you'll remember. The same steps and PIN code is used to deactivating Exam Lock.
4. If the PIN is lost,
  - a. then [connect ReaderPen to a computer](#),
  - b. select U-disk mode,
  - c. locate the ReaderPen (removable C610R) drive on the computer,
  - d. erase the "lock" file,
  - e. eject the removable C610R drive and
  - f. disconnect the USB cable.

Video demonstration:

[C-Pen ReaderPen Exam Lock](#)

### **Computer Program download:**

[C-pen Program Download](#)

This program can be use alongside of the pen if wanted. This program also allows the pen to be updated when need be. The c-pen can be used as a stand-alone product without this program. The program is available for both windows and mac devices.